



V. PATTERN DIAGRAM

1. PARTS ARRANGEMENT FOR EACH PCB ASS'Y

1) MAIN_TOP




2) MAIN_BOTTOM




V. PATTERN DIAGRAM

3) CCD_FPC




V. PATTERN DIAGRAM

5) UI_FPC




1) MAIN_BUTTON INTERFACE,AUDIO,USB,UART,SPK,X'TAL,ADC AND EJTAG




VI. CIRCUIT DIAGRAM


2) MAIN_LCD INTERFACE AND VIDEO OUT




3) MAIN_DRAM,NAND,SD INTERFACE AND CONFIGURATION RESISTORS



4) MAIN_MOTOR INTERFACE




5) MAIN_POWER AND RESET




VI. CIRCUIT DIAGRAM

6) MAIN_STROBE,GPIO AND PWM




7) MAIN_SENSOR INTERFACE for SONY




VI. CIRCUIT DIAGRAM

8) POWER




9) STROBO




VI. CIRCUIT DIAGRAM

10) CCD



11) UI_BUTTON



VI. CIRCUIT DIAGRAM

12) UI_FPC

